First Step

1. Add water



2. Add water over the U-tube heating

Second Step. Set up tempersture and humidity
Before shipping, we always have been set up.



Third Step,
After setting up, Press confrim /ok to start the test.